


MIGAT AL-IHRAM - INDEX CHART

All Carriers departing from Airports less than thirty (30) minutes from above points e.g. (Prince Mohammad Bin Abdulaziz Intl Airport, Port Sudan, Taif, Yenbo) are to advise their Passengers to change into their Ihram before departure.

MIGAT AL-IHRAM (IHRAM ZONE) Instructions: All Carriers operating flights in-bound to Jeddah are requested to announce passengers wishing to perform HAJJ or OMRAH. "we will pass abeam Migat AL-Ihram (Ihram Zone) after thirty (30) minutes from now "and they are requested to repeat the same announcement five (5) minutes before passing Migat AL-Ihram.



YENBO/Prince Abdulmohsin Bin Abdulaziz
 VOR/DME 112.9
 YEN ---
 24°08'58"N
 036°02'19"E

ABM DHU AL HOLIFAH
 (R 140 YEN/35.6NM)
 23°40'01.86"N
 038°25'04.81"E

RABIGH
 VOR/DME 116.8
 RBG ---
 22°47'31"N
 039°05'50"E

ABM AL JOHFAH
 (R 302 JDW/33.6NM)
 22°02'24.97"N
 038°38'01.54"E

JEDDAH/KING ABDULAZIZ INTERNATIONAL
 DVORTAC 115.3
 JDW ---
 21°42'44"N
 039°07'23"E

ABM YALAMLAM
 (R 206 JDW/38.3NM)
 21°10'01.04"N
 038°45'45.34"E

ABM YALAMLAM
 (R 154 JDW/82.1 NM)
 20°28'37.96"N
 039°40'54.85"E

QUNFIDAH
 VOR/DME 113.3
 QUN ---
 19°22'11"N
 041°04'29"E

AL BAHA/King Saud Bin Abdulaziz
 DVORTAC 113.5
 BHA ---
 20°17'33"N
 041°37'45"E

DAFINAH
 VOR/DME 117.5
 DFN ---
 23°16'58"N
 041°49'10"E

ABM QARN AL MANAZIL
 (R 308 TIF/11.1 NM)
 21°36'28.16"N
 040°23'52.09"E

TAIF
 DVORTAC 112.7
 TIF ---
 21°29'11"N
 040°32'50"E

MADINAH / PRINCE MOHAMMAD BIN ABDULAZIZ INTL
 DVOR/DME 114.1
 PMA ---
 24°32'51"N
 039°42'19"E

- 1 DHU AL HOLIFAH (ABYAR AL)
 24°24'49"N
 039°32'34"E
- 2 AL JOHFAH
 22°42'15"N
 039°08'50"E
- 3 THAT ERG
 21°56'08"N
 040°26'02"E
- 4 QARN AL MANAZIL (AL SAIL AL KABI)
 21°38'00"N
 040°25'38"E
- 5 YALAMLAM
 20°31'02"N
 039°52'16"E

CHANGE: JMW relocated, ATS routes revised

LEGEND	
	MIGAT AL IHRAM
	ABM MIGAT AL-IHRAM

